
Number Plate Capture Camera

● ITEM №: SGC-9980CAR



Caution for Installation

- 1. Resistor A: If you want to change the intensity of the IR light, please open the cover at the bottom of the camera(As showed in the following picture), you can adjust the IR light intensity.
- 2. Resistor B: If you want to change the working time of IR Led, please open the cover at the bottom of the camera(As showed in the following picture), you can adjust the IR LED working time." "refers to the IR LED will start working under the darker situation. "+" refers to the IR LED will start working under the brighter situation.



Packing

1.	Camera	X1
2.	User Manual	X1
3.	Screw	X4
4.	Plastic-Conical-Anchor	X4

5. Mounting drawing paper X16. Hexagonal Wrench X1

Specification

Specification			
ITEM	SGC-9980CAR		
IP Rating	IP66		
Type	Monochrome		
Signal System	NTSC/PAL		
Pick Up Device	1/3" Sony Colour High Resolution CCD		
Picture Elements	NTSC:811H×508V; PAL:795H×596V		
Resolution	560TVL		
Min Illumination	0Lux (80 Pieces IR LED ON)		
Vertical Frequency	NTSC:60Hz; PAL:50Hz		
Horizontal Frequency	NTSC:15.734KHz; PAL:15.625KHz		
Clock Frequency	NTSC:28.636MHz; PAL:28.375MHz		
Scanning System	2:1 Interlace		
S/N Ratio	≥50dB		
Electronic Shutter	NTSC:1/60-1/100,000s; PAL:1/50-1/100,000s		
Lens	9-22mm Varifocal Auto iris IR Lens		
White Balance	AUTO Tracking		
Back Light	ON		
Auto Gain Control	ON		
GAMMA	0.45		
Video Out-put	1V p-p,75 Ω		
Power Supply	DC12V ±10%/AC24V±10%		
Current Consumption	DC:380mA/AC280mA (Max)		
IR Effect Distance	2~15m (6.56~49.18ft) (Outdoor)		
Dimension	325×196×124mm (12.80"×7.72"×4.88")		
Weight	1920g (67.72oz)		
Storage Temperature	-30∼+60℃ (-22∼+140℉)		
Operating Temperature	-30~+40℃ (-22~+104°F)		

Remark: Non-regulative adaptor may cause camera damaged.

Caution for Installation

- 1. Please do not install the camera where the vibration always happens, or the camera will be damaged.
- 2. Please keep the glass in front of the camera clean. Do not touch it directly. You can use a soft cloth with alcohol to wipe if necessary.
- 3. The available IR range of this camera is shown in the specification. Please be sure to place the camera in the working distance when it works.
- 4. In order to prevent short circuit, please do not loosen any screws in the camera at random.
- 5. Please do not let the camera work in the conditions which is beyond the most extreme and demanding of operating conditions and climates shown in the specification. When any abnormalities happen, please turn off the camera and contact your local dealer or us right away.

Pay attention to the setting angle. The picture in the right is for your reference.

